











\* 4 2 9 7 7 5 5 2 1 \* (1)

©2012 Sony Corporation  
Printed in China



RDP-V20iP/SRS-GV20iP

|   |  |  |  |  |  |   |
|---|--|--|--|--|--|---|
| 1 | <p><b>English</b></p> <p>iPod classic (160 GB)<br/>iPhone 3GS<br/>iPhone 3G</p> <p><b>Nederlands</b></p> <p>iPod classic (160 GB)<br/>iPhone 3GS<br/>iPhone 3G</p>   | <p><b>Italiano</b></p> <p>iPod classic (160 GB)<br/>iPhone 3GS<br/>iPhone 3G</p> <p><b>Svenska</b></p> <p>iPod classic (160 GB)<br/>iPhone 3GS<br/>iPhone 3G</p>   | <p><b>Suomi</b></p> <p>iPod classic (160 Gt)<br/>iPhone 3GS<br/>iPhone 3G</p> <p><b>Français</b></p> <p>iPod classic (160 Go)<br/>iPhone 3GS<br/>iPhone 3G</p>   | <p><b>Español</b></p> <p>iPod classic (160 GB)<br/>iPhone 3GS<br/>iPhone 3G</p> <p><b>Português</b></p> <p>iPod classic (160 GB)<br/>iPhone 3GS<br/>iPhone 3G</p>  | <p><b>Deutsch</b></p> <p>iPod classic (160 GB)<br/>iPhone 3GS<br/>iPhone 3G</p> <p><b>日本語</b></p> <p>iPod classic (160 GB)<br/>iPhone 3GS<br/>iPhone 3G</p>  | <p><b>简体中文</b></p> <p>iPod classic (160 GB)<br/>iPhone 3GS<br/>iPhone 3G</p>  |
|   | <p><b>English</b></p> <p>iPod touch (3rd generation)<br/>iPod touch (2nd generation)<br/>iPod nano (6th generation)<br/>iPod classic (120 GB)<br/>iPod classic (80 GB)<br/>iPhone 4S<br/>iPhone 4</p> <p><b>Nederlands</b></p> <p>iPod touch (3e generatie)<br/>iPod touch (2e generatie)<br/>iPod nano (6e generatie)<br/>iPod classic (120 GB)<br/>iPod classic (80 GB)<br/>iPhone 4S<br/>iPhone 4</p> | <p><b>Italiano</b></p> <p>iPod touch (3a generazione)<br/>iPod touch (2a generazione)<br/>iPod nano (6a generazione)<br/>iPod classic (120 GB)<br/>iPod classic (80 GB)<br/>iPhone 4S<br/>iPhone 4</p> <p><b>Svenska</b></p> <p>iPod touch (3:e generationen)<br/>iPod touch (2:a generationen)<br/>iPod nano (6:e generationen)<br/>iPod classic (120 GB)<br/>iPod classic (80 GB)<br/>iPhone 4S<br/>iPhone 4</p> | <p><b>Suomi</b></p> <p>iPod touch (3. sukupolvi)<br/>iPod touch (2. sukupolvi)<br/>iPod nano (6. sukupolvi)<br/>iPod classic (120 Gt)<br/>iPod classic (80 Gt)<br/>iPhone 4S<br/>iPhone 4</p> <p><b>Français</b></p> <p>iPod touch (3<sup>e</sup> génération)<br/>iPod touch (2<sup>e</sup> génération)<br/>iPod nano (6<sup>e</sup> génération)<br/>iPod classic (120 Go)<br/>iPod classic (80 Go)<br/>iPhone 4S<br/>iPhone 4</p> | <p><b>Español</b></p> <p>iPod touch de (3ª generación)<br/>iPod touch de (2ª generación)<br/>iPod nano de (6ª generación)<br/>iPod classic (120 GB)<br/>iPod classic (80 GB)<br/>iPhone 4S<br/>iPhone 4</p> <p><b>Português</b></p> <p>iPod touch (3.ª geração)<br/>iPod touch (2.ª geração)<br/>iPod nano (6.ª geração)<br/>iPod classic (120 GB)<br/>iPod classic (80 GB)<br/>iPhone 4S<br/>iPhone 4</p> | <p><b>Deutsch</b></p> <p>iPod touch (3. Generation)<br/>iPod touch (2. Generation)<br/>iPod nano (6. Generation)<br/>iPod classic (120 GB)<br/>iPod classic (80 GB)<br/>iPhone 4S<br/>iPhone 4</p> <p><b>日本語</b></p> <p>iPod touch (第3世代)<br/>iPod touch (第2世代)<br/>iPod nano (第6世代)<br/>iPod classic (120 GB)<br/>iPod classic (80 GB)<br/>iPhone 4S<br/>iPhone 4</p> | <p><b>简体中文</b></p> <p>iPod touch (第3代)<br/>iPod touch (第2代)<br/>iPod nano (第6代)<br/>iPod classic (120 GB)<br/>iPod classic (80 GB)<br/>iPhone 4S<br/>iPhone 4</p> |
| 3 | <p><b>English</b></p> <p>iPod touch (4th generation)<br/>iPod nano (5th generation)<br/>iPod nano (4th generation)<br/>iPod nano (3rd generation)</p> <p><b>Nederlands</b></p> <p>iPod touch (4e generatie)<br/>iPod nano (5e generatie)<br/>iPod nano (4e generatie)<br/>iPod nano (3e generatie)</p>   | <p><b>Italiano</b></p> <p>iPod touch (4a generazione)<br/>iPod nano (5a generazione)<br/>iPod nano (4a generazione)<br/>iPod nano (3a generazione)</p> <p><b>Svenska</b></p> <p>iPod touch (4:e generationen)<br/>iPod nano (5:e generationen)<br/>iPod nano (4:e generationen)<br/>iPod nano (3:e generationen)</p>   | <p><b>Suomi</b></p> <p>iPod touch (4. sukupolvi)<br/>iPod nano (5. sukupolvi)<br/>iPod nano (4. sukupolvi)<br/>iPod nano (3. sukupolvi)</p> <p><b>Français</b></p> <p>iPod touch (4<sup>e</sup> génération)<br/>iPod nano (5<sup>e</sup> génération)<br/>iPod nano (4<sup>e</sup> génération)<br/>iPod nano (3<sup>e</sup> génération)</p>   | <p><b>Español</b></p> <p>iPod touch de (4ª generación)<br/>iPod nano de (5ª generación)<br/>iPod nano de (4ª generación)<br/>iPod nano de (3ª generación)</p> <p><b>Português</b></p> <p>iPod touch (4.ª geração)<br/>iPod nano (5.ª geração)<br/>iPod nano (4.ª geração)<br/>iPod nano (3.ª geração)</p>  | <p><b>Deutsch</b></p> <p>iPod touch (4. Generation)<br/>iPod nano (5. Generation)<br/>iPod nano (4. Generation)<br/>iPod nano (3. Generation)</p> <p><b>日本語</b></p> <p>iPod touch (第4世代)<br/>iPod nano (第5世代)<br/>iPod nano (第4世代)<br/>iPod nano (第3世代)</p>  | <p><b>简体中文</b></p> <p>iPod touch (第4代)<br/>iPod nano (第5代)<br/>iPod nano (第4代)<br/>iPod nano (第3代)</p>  |

**1****2****3****4****5****6**